





B1147AA



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Handle, w/logo-red	B961308AA	1 Set	12	Connecting group	B960471NU	1 Set
1a	Handle, w/logo-blue	B961307AA	1 Set				
2	Screw M5x6		2 Pcs.				
3	Block cap	A961157AA	1 Pcs.				
4	Indicator-red		1 Pcs.				
4a	Indicator-blue		1 Pcs.				
5	Screw M4x8		2 Pcs.				
6	Adapter+screw	A861446NU	1 Set				
7	Ceramic valve G1/2, 90°-RH	A861244NU*	1 Pcs.				
7a	Ceramic valve G1/2, 90°-LH	A861243NU*	1 Pcs.				
8	Body pillar tap G3/4		2 Pcs.				
9	Flow straightener	B960998NU	2 Pcs.				
10	O-Ring Ø18.2x1.7	A961640NU	2 Pcs.				
11	Connector G3/4		2 Pcs.				

*Universal set (not all parts needed)